

REVO SX 3,5-7A

Diagram of control connection 4x3,5A - 230V




Diagram of control connection 4x3,5A - 480V




Diagram of control connection 3x4,5A - 230V




Diagram of control connection 3x4,5A - 480V




Diagram of control connection 2x7A - 230V





Diagram of control connection 2x7A - 480V



REVO SX 50-90A

Diagram of control connection examples

