

REVO SSR

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
ORDER CODE	S	S	R	-	-	-	-	-	-	-	-	-	-	-	-	-	-

CURRENT	4	5	6	
description	code			note
62A	0	6	2	
74A	0	7	4	
90A	0	9	0	

MAX VOLTAGE	7	
description	code	note
480V	4	
600V	6	

VOLTAGE SUPPLY AUX	8	
description	code	note
No auxiliary voltage supply	0	

INPUT	9	
description	code	note
SSR	S	

FIRING	10	
description	code	note
Zero Crossing Z	Z	
Random (For connection with REVO PC)	R	

CONTROL MODE	11	
description	code	note
Open Loop	0	

FUSES & OPTION	12	
description	code	note
No Fuse	0	

FAN VOLTAGE	13	
description	code	note
No fan	0	

APPROVALS	14	
description	code	note
CE EMC For European Market	0	

MANUAL	15	
description	code	note
None	0	
Italian	1	
English	2	
German	3	
French	4	

VERSION	16	
description	code	note
Std version	1	